

KIDS QUAD RIDE ON ATV MANUAL

- Forward
- Backward
- Turn right
- Turn left
- Stop
- Light



• Product Size: 116*64*80CM

WARNING :Not to be used in traffic.

This product is designed for children age 3+.
Original License Counterfeit Investigated

The company has passed the ISO 9001:2008 quality management system certification

SPARE PARTS LIST



Parts name	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
Qty	1	1	1	1	1	2	1	4	8	5	4	2	1	2	

I. WHEELS INSTALLATION

Please check the different of the wheels (according to the follow photo)



Assembly Instructions:
Take off the nuts from the axle.
Take turn to fix the gasket (need not put the gasket to inside of the rear wheels), wheels, gasket, nut (fixed by the spanner), small wheels cover.



II. Steering lever and dashboard installation

Assembly Instructions:
Fixed the steering lever into the dashboard.
Align them with the ATV slot, please do not fixed.
Make the connect wire into the ATV slot,too.
Take out the connect wire from the circular part (according the photo)



III. Connect wire installation

Take out all of the connect wire , connect the same color connection.



IV. Battery connect

Assembly Instructions:
Take off the plastic of insulation, red connection to red terminal.



WHILE CONNECTING TO THE STORAGE BATTERY TAKE CARE THAT THEY ARE CORRECTLY CONNECTED TO ENSURE THE RIGHT POLARITY

black connect black terminal
red terminal red connect

V. Dashboard installation

Check and confirm the function of lights and sound.
Push the dashboard until full into place. (according the photo)



VI. Steering level installation

Fixed the steering lever . Use the gasket and nuts by spanner.



VII. Hood installation

Align the hood with the ATV slot and push until full into place.



VIII. Front support frame installation

Align the front support frame with the ATV slot and push until full into place.



IX. Rearview Mirror installation

Align the rearview mirror with the ATV slot and push until full into place. (according the photo)



Remark : Left and right rearview mirror is different.

X. Flagstaff installation

Align the flagstaff with the ATV slot and push until full into place. (according the photo)



Explosive View



■ CHARGING PRECAUTIONS BEFORE USE

Please read manual carefully before use.

Before operating the vehicle, check if there has been wear or damage to the battery, charger, connectors and any other part of the vehicle. If any damage is found, contact the seller to have the charger repaired or replaced immediately. Do not use a damaged product.

To get started,


1. Press the power switch to OFF position to turn the power off. Open the seat, connect the battery plugs, with the red and black wires to their respective terminals. Please ensure the red wire is connected to the red battery terminal and the black wire is connected to the black battery terminal;
2. Ensure that the battery is secured to the car with the bracket. Otherwise the battery may loosen and fall out.

■ BATTERY & CHARGING

After first use, charge the battery for 8-10 hours until battery is fully charged. Subsequent charges should be 6-8 hours, but not exceeding 10 hours. **TURN OFF THE POWER SWITCH WHEN CHARGING**

Batteries should still be charged at least once a month in order to keep the cells active.

1. Open the cover of charging socket on the car.
2. Plug the charge into the charging socket.
3. Plug the other end of the charger into your wall socket.



DO:

- Recharge the battery when you notice a decrease in speed and power is the car.
- Charge at least once a month to keep the battery cells active.
- Only adults (aged 12+) should be handling the battery/adaptor
- Operate the battery and charger specified according to the manual instructions.
- The battery is heavy and contains sulfuric acid (electrolyte). Dropping the battery could result in serious injury. Handle with care.

DO NOT:

- Do not use the car until the battery is drained completely or to a crawling speed.
- Do not reverse battery polarity or connect wires to a short circuit.
- Do not allow children under the age of 12 to handle the battery.
- Do not open the battery and the charger.

It is normal for the battery/adaptor to feel warm while charging, but if it feels too hot, stop charging immediately and check battery/adaptor.

■ TROUBLESHOOTING COMMON PROBLEMS

Problem 1: The car will not move.

- Charge battery for 6-8 hours. The battery is likely low on charge.
- Making sure the charger and the car has been removed from the car charging point.
- The battery wires are not connected. Please check the connections on the battery terminals are firmly in place.

Problem 2: The car only drives for a short time/distance.

- Charging the battery for 6-8 hours. The battery is likely low on charge.
- Keep the battery active by charging the battery at least once a month to keep the active.
- Replacing the battery. The battery may need to be replaced depending due to natural deterioration of its charging history and age.

Problem 3: The audio does not work.

- Ensuring the volume is turned up and the MP3 lead is not connected. The steering wheel sounds will not work when the MP3 is plugged into the car.

Problem 4: Charger makes a buzzing sound while charging

This is normal.

Problem 5: Charger overheating.

It is normal for the battery and charger to warm slightly during charging. If they feel excessively hot then please check for a current overload or battery short circuit.

Problem 6: Unable to charge car.

- Making sure that the battery wires are connected properly. Check that the connections on the battery terminals are firmly in place, with the red wire in the red terminal and respectively for the black wire.
- Ensure that the charger is properly inserted into place
- During charging, make sure the charger is plugged into the power outlet correctly. The charger may feel slightly warm while charging.

If the battery, car body wiring, charger or motor is still not working correctly. Please contact the agent or manufacturer for further assistance.

To avoid fuse cut off the power:

1. Max: 30kgs, overload is forbidden
2. Do not drag any item behind this product.
3. Do not allow water or other liquids dip the electrical parts.
4. Do not change the line system by yourself.

■ BATTERY DISPOSAL

Your sealed lead-acid battery must be recycled or disposed of in an environmentally sound manner.

- Do not dispose of lead-acid battery in a fire. The battery will explode.
- Do not dispose of lead-acid battery in your regular household trash. The incineration land filling or mixing of sealed lead-acid batteries with household trash is prohibited by law.
- Return an exhausted battery to your local approved lead-acid battery recycle, such as a local seller of automotive batteries.
- Contact your local waste management officials for information on how to environmentally recycle & dispose of lead-acid batteries.



■ DASHBOARD FEATURES & FUNCTIONS



- 1) Volume adjust
 - 2) Power display
 - 3) MP3 interface
 - 4) Low/High speed
 - 5) Forward/Backward switch
 - 6) Key start as real car, insert the key and turn it on.
 - 7) Accelerator pedal
- A & B) Horn & Music Button



1. Press the music button on the steering wheel for horn or music.
2. Attach the MP3 lead to your device to play or own music through the car. Please note the steering wheel sounds were not work when the MP3 lead is connected.

■ WARNING AND HAZARDS

WARNING: Vehicle must be charged fully before use.

Failure to do so voids warranty.

Warning: Not to be used in traffic

Adult assembly required.

Always wear a helmet and protective clothing when riding.

Continuous adult supervision required when using this product.

Charging the battery can only be done by adult at all times.

Please keep the manual and packaging for future reference as it contains important information.

The instructions for use should bear a reminder that the toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.

■ SAFETY PRECAUTIONS

- While riding, adult supervision is required all the time. Always wear a helmet when driving.
 - Do not drive near streets, roads or on sidewalks and footpaths. It is not recommended to drive the vehicle on wet surfaces or on slopes greater than 15-degree.
 - It is recommended to drive this vehicle on smooth surface only, not meant for offroad or rough terrain.
 - Do not drive this vehicle outdoors when it is raining.
 - Make sure that the vehicle stop completely before changing direction from forward to reverse.
 - Clean the vehicle with a dry cloth only.
- Please follow the correct weight and age limits allowed to drive this vehicle.
- It is prohibited to change the circuit or add other electric parts. Adults must teach their children about safe driving procedures. Turn the power off when not in use.
 - Check the seat to ensure it has been fitted and secured with a bolt before driving.
 - Inspect all wires and connections of the vehicle periodically.
 - Charging the battery should only be done by adults.
 - Charging plug is located underneath the seat.
 - Don't let children touch the wheels or be near them when the car is in motion

Please read manual carefully before use.

These are recommended guidelines to follow for the rider to have a positive ride experience. Failure to abide by the above guidelines may cause harm and injury to the liability of the buyer and cause the issued warranty to the buyer to be void.

Warranty period is 90 days from the date of purchase.

Proof of purchase must be given for goods to be returned, repaired or replaced.



Implementation of national standards: EN71, EN62115, CE, ROHS